# **PRODUCTS**

## 9 Watt LED Light Bulb

This 9 watt dimmable LED light bulb is equivalent to a 60 watt incandescent bulb. It provides 25,000 hours of service, lasting up to 25 times longer and using 80% less energy than older incandescent bulbs. This LED bulb can be used in enclosed fixtures and are equipped with a 220° beam angle that produces even light from the socket base in a wide direction. This bulb also has a standard medium base which allows it to be easily installed into existing standard-sized lamps and fixtures.

## Caulk Gun

This Caulk Gun has a steel body and holds a standard 10.3 oz cartridge. It is made of corrosion resistant epoxy and has a mechanical advantage of 6:1.

## **Acrylic Adhesive Silicone Sealant**


This Acrylic Adhesive Silicone Sealant is ideal for sealing or setting windows, trim, doors, sinks, counters and a variety of substrates.

## Closed-Cell Foam Weather-Strip

This Adhesive-backed weather stripping, good for sealing out drafts in doors and windows.

#### To Install-

- 1. Remove any existing tape.
- 2. Clean the surface and allow it to dry completely.
- 3. Cut the tape to desired length with scissors.
- 4. Press in place with fingertips.
- 5. Apply to the door frame with the creased side-facing the door on all sides.
- 6. Make sure the tape is compressed by the closed door.



This Earth® Showerhead saves money by using less water than traditional showerheads. It ensures drastic water usage reductions and features a nine-jet adjustable turbo massage that easily rotates from a gentle needle spray to a forceful jet.

#### To Install:

- 1. Remove the old showerhead from the shower arm by turning it counter-clockwise
- 2. Clean the shower arm threads, then turn on the water to wash out the pipe
- 3. Turn off the water
- 4. Apply a few layers of pipe tape directly to the shower arm threads in a clockwise direction
- 5. Apply the screen washer firmly onto the showerhead
- 6. Hand-tighten the showerhead onto the shower arm

### **Faucet Aerator**

This aerator is made to fit standard sized bathroom and kitchen faucets. This product maintains great water pressure while saving water and energy.

#### To Install:

- 1. Remove old aerator from faucet
- 2. Before installing the new aerator, turn on the water to wash out the faucet
- 3. Turn off the water

## **Inside Threaded Faucets:**

- 4. Place two rubber washers in the top of the aerator
- 5. Screw the aerator into the inside threads of faucet and hand-tighten

#### **Outside Threaded Faucets:**

- 4. Place one rubber washer in the top of the aerator.
- 5. Screw the aerator into the inside threads of faucet and hand-tighten

Note: Occasionally remove the aerator and rinse the pieces



